

P32012ARMU/P32012SBMU



| | |
|---|---|
| ① | Seat ass'y |
| | 32200227 (Seat ass'y) |
| | 32222093 (CAPTAIN SEAT ONLY,18W*16D*18H,MC26) |
| | 43701072 (PAD, ARMREST(LONG),BLACK) |
| | 43701073 (PAD,ARMREST(SHORT),BLACK) |
| ② | Battery Pack Ass'y |
| | 33700068(BATTERY PACK ASS'Y.,22AH, BLACK, P320) |
| ③ | Drive wheel ass'y |
| | 32600430 (DRIVER WHEEL, 2.80/2.50-4 PU,GRAY) |
| ④ | Motor and gearbox complete, LH and RH. |
| | 62011007 (MOTOR & GEARBOX ASS'Y.,LH, M75AE-28) |
| | 62021007 (MOTOR & GEARBOX ASS'Y.,RH, M75AE-28) |
| | 62111004 (MOTOR ASS'Y., M7AE/F, LH) |
| | 62121004 (MOTOR ASS'Y., M7AE/F, RH) |
| | 62411006 (GEARBOX ASS'Y., M75-28,LH) |
| | 62421006 (GEARBOX ASS'Y., M75-28,RH) |

| | |
|---|--|
| ⑤ | Caster Wheel with Fork Ass'y. |
| | 33100152 (CASTOR FORK ASS'Y., LH7*1-3/4" PU) |
| | 33100153 (CASTOR FORK ASS'Y., RH7*1-3/4" PU) |
| ⑥ | Controller |
| | 33603053 (JOYSTICK BRAKET ASS'Y.,VR2, ED) |
| | 64820002 (JOYSTICK ONLY, P&G VR2,JSM D50677) |
| | 64220004 (CONTROLLER, PG VR2-40AD50940) |
| ⑦ | Shroud ass'y |
| | 30510833 (SHROUD ASS'Y., CANDYAPPLE, P320) |
| | 30515931 (SHROUD ASS'Y, BLUE,P320) |
| ⑧ | Footplate ass'y. |
| | 42500157(FOOTREST PLATE) |
| ⑨ | Charger unit |
| | 65142007(CHARGER, HP8204-3A-OFF) |
| | 63600008(CHARGER POWERCORD W/PLUG,US SPEC) |