



Liftavators are designed to provide limited use/limited application (LU/LA) elevator service, up to 25 feet, in new and existing building where space and economy are prime considerations

Built to ASME/ANSI A17.1-2003Part 5, Section 5.2., Liftavators are built to the same rigid specifications required of full-sized commercial elevators. This ensures that they can meet the needs of the most demanding applications.

Liftavators are installed in completely enclosed fire-rated hoistways to meet applicable building codes. Doors and gates are fully interlocked for maximum safety. Built with components of proven design and manufacture, Liftavators are safe, reliable and easily maintained.

GENERAL SPECIFICATIONS

POWER SUPPLY:	220V, 30 AMP, SINGLE PHASE, 60 HZ
DRIVETYPE:	DIRECT ACTING HYDRAULIC CYLINDER
CONTROLS:	AUTOMATIC OR KEY CONTROLS
RATED LOAD:	1400 LB. COMMERCIAL, OTHERS ON REQUEST
PLATFORM:	UP TO 18 SQUARE FEET, 11 GA STEEL OTHERS ON REQUEST
CAR PANELING:	1/2" MELAMINE OR ACRYLIC PANELS MULTIPLE COLOR CHOICES AND CUSTOM FINISHES AVAILABLE
TRAVEL:	UP TO 25 FT. AT 30 FPM, UP TO 50' WITH VARIANCE
MISCELLANEOUS:	COMPACT, QUIET, COMMERCIAL HYDRAULIC POWER UNIT, PUMP MOTOR, AND RESERVOIR IN ONE PACKAGE

STANDARD FEATURES

- Automatic or key control
- Commercial fixtures/controls
- Commercial carpet flooring
- Illuminated push buttons
- Emergency light package
- Instruction certificate frame
- Pump timer
- Solid panel aluminum, stainless, or wood car gates
- Time delayed door closer
- UL Listed "B" Label, 1 1/2 hour fire rated EZ Entry hoistwa doors to meet building codes
- Self-leveling
- Formica brand melamine wall panels
- Stainless steel handrail
- Emergency stop button
- Alarm bell
- Non-interference timer
- Over speed check valve
- Power-off lowering/Battery back-up system
- Emergency phone
- 5 year warranty

OPTIONAL FEATURES

- Priority (fast track) scheduling
- Power operated hoistway swing doors with battery back-up
- Vandal proof fiberglass or stainless paneling
- Executive package - includes bronze gate, fixtures, trim & sill
- Power operated sliding car and hoistway doors
- Hi-speed valve and power unit