

American Tubs CARE Series 2653

Compact Size / Energy Efficient



Specifications:

Actual size (W x L x H) 25.5" x 52.5" x 36"

Shipping size (W x L x H) 28" x 54" x 44"

Seat High 17"

Seat Width 20.5"

Seat Depth 14"

Door Opening 15.5"

In-side length 43.5"

Water Capacity (Gal.) 45

Colors Available White / Biscuit

Door Opening / Drain Left / Right

Wall Tiles Flange None (easy-to-install)

Options:

- Soaking
- Hydro Massage
- Air Massage

Features include:

- Tub shell - gel coat fiberglass
- High quality fiberglass material

- Excellent color uniformity
- Durable gel coat surface
- Easy-to-clean high gloss finish

Optional features:

- Hand Shower Wall Slider Bar Chrome Finished (Standard)
- Hand Shower Wall Slider Bar Chrome Finished (All brass)
- Safety Grab Bar (Addition)
- Headrest Pillow
- Aromatherapy kits
- Ozone sterilizer
- Chromatherapy system
- L shaped curtain & rod
- Water In-line heater

Ergonomic door-sill with silicone rubber seal
 Built-in safety grab bar
 Removable access panels
 Wall extension kit to fit in standard 60" opening
 Anti-slip floor
 Door Drain Included

Therapeutic Air Massage System

- Twenty (20) all brass chrome air jets
- 110V-120V. Standard Plug-In, 1hp Air Pump
- Pneumatic push control chrome color

Hydrotherapy Massage System

- Six (6) adjustable direction Hydro jets
- 110V-120V. Standard Plug-In, 1hp Hydro Pump
- Pneumatic push control chrome color

Faucets

Faucet with Hand Shower is mounted on deck of the tub.

- Five (5) Piece Brass Roman Faucet in Chrome
- Jewel Arched Solid Brass Spout
- 3/4" Valve, 3/4" Ports
- Ceramic Disc Cartridges
- Quick Connect Spout Installation
- NPS Connections
- Shower handheld
- 18 GPM (Average) @ 60 PSI

Warranty

- Lifetime limited warranty on stainless steel frame, door, door seal and tub shell.
- 2 Years Limited parts warranty *

